



**FAA-APPROVED**

## **AIRPLANE FLIGHT MANUAL SUPPLEMENT**

FOR

BEECHCRAFT MODEL:

33 SERIES, 35 SERIES, 36 SERIES, 55 SERIES,  
56 SERIES, 58 SERIES, 95 SERIES

REGISTRATION NUMBER:

SERIAL NUMBER:

This supplement must be attached to the FAA Approved Beechcraft Model 33, 35, 36, 55, 56, 58, and 95 Series Airplane Flight Manual when the Main Landing Gear Auxiliary Landing Lights have been installed in accordance with this Supplemental Type Certificate SA00469NY & SA00802NY.

The information contained herein supplements or supersedes the basic manual only in those areas listed. For limitations, procedures, performance, and loading information not contained in this supplement, consult the basic Airplane Flight Manual.

FAA Approved: \_\_\_\_\_  
Manager, Southwest Flight Test Section, AIR-713  
Federal Aviation Administration  
Ft. Worth, TX

## REVISIONS

<b>Revision No</b>	<b>Affected Pages</b>	<b>Description</b>	<b>FAA Approved</b>
02	All	STC Re-issued to Gallagher Aviation LLC	

**AIRPLANE FLIGHT MANUAL SUPPLEMENT**  
**FOR STCs: SA00469NY & SA00802NY**

1. LIMITATIONS

- a. NO CHANGE

2. PROCEDURES

a. PREFLIGHT

- i. Left Landing Gear: Auxiliary Landing Light: **SECURE**
- ii. Left Slip Marker – **CHECK**
- iii. Right Landing Gear: Auxiliary Landing Light: **SECURE**
- iv. Right Slip Marker – **CHECK**

b. OPERATING PROCEDURES

- i. The Main Landing Gear Auxiliary Landing Lights are controlled by a two position “ON-OFF” switche located on the instrument panel.
  - 1. To illuminate – **ON**
  - 2. To turn off – **OFF**

3. PERFORMANCE

- a. NO CHANGE

4. LOADING INFORMATION

- a. NO CHANGE